

REVISIONS								
ZONE	REV	DESCRIPTION	DATE	APPROVED				
	J	UPDATED SCHEMATIC AND TORQUE TABLE	11/5/20	JED				
	К	UPDATED SIM-ALM CIRCUIT BOARD	12/1/20	AO				





SIM-ALM, TB1 3 4 5 6 7 8 9 10

SIM-ALM, TB1 3 4 5 6 7 8 9 10

SIM-ALM, TB1 3 4 5 6 7 8 9 10

SIM-ALM, TB1 3 4 5 6 7 8 9 10

SIM-ALM, TB1 4 5 6 7 8 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 6 7 8 9 9 10

SIM-ALM, TB1 5 7 8 9 9 10

SIM-ALM, TB1 5 7 8 9 9 10

SIM-ALM, TB1 5 8 9 10

SIM-ALM, TB1 5 8 9 10

SIM-ALM, TB1 5 8 9 10

SIM-ALM, TB1 5

MULTI-TAP TRANSFORMER:

20

21

22

CONNECT FACTORY TAGGED WIRES TO APPROPRIATE TRANSFORMER VOLTAGE TAP. SEE BELOW FOR CONNECTIONS:

FOR 208V OPERATION, CONNECT TO FUSE INPUT HF & TO TRANSFORMER TAP H2.

FOR 240V OPERATION, CONNECT TO FUSE INPUT HF & TO TRANSFORMER TAP H3.

FOR 480V OPERATION, CONNECT TO FUSE INPUT HF & TO TRANSFORMER TAP H4.

DASHED LINE INDICATES FIELD WIRING.

USE COPPER CONDUCTORS ONLY.

DRY CONTACT -> DRY CONTACT HIGH LEVEL ALARM (N.O.)

DRY CONTACT -> DRY CONTACT COMMON 120VAC / 24VDC, 1 AMP MAX

8-

TEMPERATURE RATING OF CONDUCTORS IS TO BE: 60°C (140°F) FOR UNDER 100A. 75°C (167°F) FOR OVER 100A.

BRANCH CIRCUIT PROTECTION SHALL BE PROVIDED BY THE INSTALLER: MUST BE SIZED ACCORDING TO PUMP/MOTOR MANUFACTURING SPECIFICATIONS.

VERIFY CORRECT OPERATION OF CONTROL PANEL AFTER INSTALLATION IS COMPLETE.

		_									
FIELD WIRING TORQUE SPECS.		DRAWN BY:	DATE:					rd do			
TERMINAL BLOCK UT 2,5	5 IN-LB	KJ	6/8/14					ا نمیکر ال			
TERMINAL BLOCK UT 4	7 IN-LB			1							
TERMINAL BLOCK UT 6	15 IN-LB	APPROVED BY:	DATE:				\sim				
TERMINAL BLOCK UT 10	15 IN-LB	T KM I	6/8/14	TITLE:							
TERMINAL BLOCK UT 16	25 IN-LB			SIM-A3-(1-10)							
TERMINAL BLOCK UT 35	ERMINAL BLOCK UT 35 30 IN-LB		THIS DRAWING CONTAINS		, ,						
TB1 & TB2 PCB 5 IN-LB		PROPRIETARY INFORMATION		CONTROL SCHEMATIC							
TRANSFORMER H1F, H2F & H3F	RANSFORMER H1F, H2F & H3F 15 IN-LB		AND SHALL NOT BE USED								
TRANSFORMER H1, H2 & H3	10 IN-LB	· · · · · · · · · · · · ·		SIZE	DWG NO.		PART NO.			REV	
DS1 VLS3P63-125 R2	45 IN-LB	OR DISCLOSED				1508	C	M-A3-	(1 10)	12	
DS1 LK4JU3CN 100A	36 IN-LB] PRIOR WRIT	TEN	B		1300	3	IM-AJ-	(1-10)	n	
DS1 LK4MU3N 200A	200 IN-LB] AUTHORIZAT	ION.	COALE	NONE			CHEET	1 (${\sqrt{\Gamma}}$	
M1/M2 T1, T2, & T3	15 IN-LB			SCALE	NONE			SHEET		<i>/</i>	